

- iii. Press and hold admin button a second time until LED turns solid yellow. Release button. **LED must be yellow to connect from your PC.**
- f. Enter the reader-controller's serial number and Master PIN in the *Set VP1 or EZ1 Identity* section.
- g. Click the 'Connect' button in the *Connect to VP1 Reader* section.
- h. Once connected, click the 'Do Update' button at the bottom of the program to begin the firmware upgrade.
 - i. The reader-controller will flash yellow during the upgrade process.
 - j. Allow the upgrade to complete and do not power off the PC/laptop, VIZpin reader-controller, or disable Bluetooth.
 - k. The reader-controller will flash green for several seconds, and then solid green during final phases of upgrading.
 - l. When the LED returns to pulsing red, the firmware upgrade is complete.



The firmware upgrade does not change the active settings on the reader and the current settings may or may not be valid for your specific installation or VIZpin account type. Apply the appropriate settings by way of VIZpin LINK to ensure the reader-controller will operate as expected.

Review our videos at <http://vizpin.com/tech-tip-videos>.

Recommended PC Specs

- Windows 7 OS or higher (32- or 64-bit) w/sufficient user permissions to download and install new software, and locate/connect new devices
- Bluetooth radio running BT v2.0 and up (internal or external adapter)
- Generic Bluetooth Radio and Microsoft Bluetooth Enumerator drivers (as displayed in Windows Device Manager)